


Network Camera

Quick Guide



Safety Precautions

WARNING

RISK OF ELECTRIC SHOCK
DO NOT OPEN

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Important Safeguards

1. Read Instructions

All the safety and operating instructions should be read before the appliance is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Cleaning

Unplug this equipment from the wall outlet before cleaning it. Do not use liquid aerosol cleaners. Use a damp soft cloth for cleaning.

4. Attachments

Never add any attachments and/or equipment without the approval of the manufacturer as such additions may result in the risk of fire, electric shock or other personal injury.

5. Water and/or Moisture

Do not use this equipment near water or in contact with water.

6. Placing and Accessories

Do not place this equipment on a wall or ceiling that is not strong enough to sustain the camera. The equipment may fall, causing serious injury to a child or adult, and serious damage to the equipment. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.



This equipment and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the equipment and cart combination to overturn.

Do not place this equipment in an enclosed space. Sufficient ventilation is required to prevent an increase in ambient temperature which can cause malfunction or the risk of fire.

7. Power Sources

This equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power, please consult your equipment dealer or local power company.

You may want to install a UPS (Uninterruptible Power Supply) system for safe operation in order to prevent damage caused by an unexpected power stoppage. Any questions concerning UPS, consult your UPS retailer.

8. Power Cord

Operator or installer must remove power and TNT connections before handling the equipment.

9. Lightning

For added protection for this equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the equipment due to

lightning and power-line surges. If thunder or lightning is common where the equipment is installed, use a surge protection device.

10. Overloading

Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

11. Objects and Liquids

Never push objects of any kind through openings of this equipment as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the equipment.

12. Servicing

Do not attempt to service this equipment yourself. Refer all servicing to qualified service personnel.

13. Damage requiring Service

Unplug this equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or the plug has been damaged.
- If liquid is spilled, or objects have hit the equipment.
- If the equipment has been exposed to rain or water.
- If the equipment does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the equipment to its normal operation.
- If the equipment has been dropped, or the cabinet damaged.
- When the equipment exhibits a distinct change in performance — this indicates a need for service.

14. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

15. Safety Check

Upon completion of any service or repairs to this equipment, ask the service technician to perform safety checks to determine that the equipment is in proper operating condition.

16. Field Installation

This installation should be made by a qualified service person and should conform to all local codes.

17. Correct Batteries

Warning: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

18. Tmra

A manufacturer's maximum recommended ambient temperature (Tmra) for the equipment must be specified so that the customer and installer may determine a suitable maximum operating environment for the equipment.

FCC Compliance Statement

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE, IN WHICH CASE USERS WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT THEIR OWN EXPENSE.

WARNING: CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT. THIS CLASS OF DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE CAUSING EQUIPMENT REGULATIONS.

WEEE (Waste Electrical & Electronic Equipment)

Correct Disposal of This Product

(Applicable in the European Union and other European countries with separate collection systems)



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Manufacturer reserves all rights concerning this document.

Use or duplication of this document in part or whole without the prior consent of manufacturer is strictly prohibited.

The information in this document is believed to be accurate as of the date of publication even though explanation about some functions may not be incorporated. The manufacturer is not responsible for any problems resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this publication may be issued to incorporate such changes.

This product contains software built partially on open-source content. Codes for the corresponding open-source content are available for download. For more information, refer to the software CD (OpenSourceGuide\OpenSourceGuide.pdf) or the open source guide accompanying this document.

Accessories

Upon purchasing the product, check inside the box to make sure all the following accessories are included. Some parts may differ depending on the situation.

| Item |
|---|
| Network Camera |
| Ferrite Core |
| Installation CD (INIT/INEX Basic software, Manuals) |
| Quick Guide |
| Allen wrench (included with <i>Vandal dome</i> model only.) |
| Screws, Anchor (3 ea.) |
| Desiccant |
| Cable Access Hole Rubber |

Overview




- Product color and design may vary depending on the model.
- For more details on each part name, refer to the operation manual.


Dome Cover

Top

Vandal Dome Model




Plastic Dome Model




Bottom

Vandal Dome Model




Shield Case

IR LED Non-Supported Model




| | | | |
|---|-------------------|---|-------------------|
| 1 | Side Cable Access | 3 | Dome Cover Screws |
| 2 | Safety Wire | 4 | Shield Case |


Plastic Dome IR LED Non-Supported Model



Plastic Dome IR LED Supported Model




Vandal Dome Model



| | |
|----|------------------------------------|
| 1 | IR LED |
| 2 | Lens |
| 3 | Lens Rotator |
| 4 | Horizontal Rotator |
| 5 | SD Memory Card Slot |
| 6 | Factory Reset Switch |
| 7 | Safety Wire Screw Hole |
| 8 | O-Ring Groove |
| 9 | Wall/Ceiling Installation Hole |
| 10 | Dome Cover Screw Hole |
| 11 | Bottom Cover |
| 12 | I/O Device Port |
| 13 | Cable Access Hole |
| 14 | Vertical Rotation Adjustment Screw |


I/O Device Port




| | | | |
|---|-----------|---|--------------|
| 1 | Alarm I/O | 5 | Network LED |
| 2 | Audio I/O | 6 | Network Port |
| 3 | Video Out | 7 | Power LED |
| 4 | Power | | |


Camera Installation



Installation


 Check the wall or ceiling to see if it needs to be reinforced. The camera may fall off if the wall or ceiling is not strong enough to support its weight.

 Shield case is included with *IR LED non-supported model* only.

Vandal Dome Model

 Attach the enclosed desiccant beside the safety wire screw inside the dome cover to prevent moisture. *vandal dome model* only.





- 1 Use the screws provided with the camera to secure the bottom cover on a wall or a ceiling.




Use the provided guide pattern to check the distance between the screws.

- 2 Connect external devices, the network cable, and the power adapter. If the camera is **vandal dome model**, block the cable access hole for waterproofing by using the enclosed cable access hole rubber when routing cables and wires. Waterproofing sealing is required by using silicone etc. after blocking the cable access hole. Ask your retailer for details.

- 3 Adjust the angle of the lens. For more information, refer to the **Angle Adjustment**.
- 4 Adjust the focus and zoom levers.
- 5 Attach the shield case to the vertical rotation adjustment screw and secure it in place.
IR LED non-supported model only
- 6 Attach the dome cover to the bottom cover.
- **Vandal dome model**: Use the provided screws to secure the dome cover on to the bottom cover.
 - **Plastic dome model**: Align the marking next to the cable access hole on the bottom cover and the side cable access hole on the dome cover together and then turn the dome cover in clockwise direction to lock it in place.
- 7 Connect the power.


Angle Adjustment



| | |
|---|---------------------|
| 1 | Lens Rotation |
| 2 | Vertical Rotation |
| 3 | Horizontal Rotation |

Specifications

General

| | | |
|---|---------------------------|---|
| External Dimensions (Ø x H) | | 159mm x 122mm (6.3" x 4.8") |
| Packaging Dimensions (W x H x D) | | 205mm x 175mm x 205mm (8.1" x 6.9" x 8.1") |
| Weight (Main Unit) | Vandal dome model | 0.87kg (1.9 lb) |
| | Plastic dome model | 0.51kg (1.1 lb) |
| Weight (Packaging) | Vandal dome model | 1.18kg (2.6 lb) |
| | Plastic dome model | 0.82kg (1.8 lb) |
| Working Temperature | | -10°C ~ 50°C (14°F ~ 122°F) [Starting Temperature: 0°C ~ 50°C (32°F ~ 122°F)] |
| Operating Humidity | | 0% ~ 90% |
| Power Input | | 12 VDC, PoE (IEEE 802.3af, Class 2) |
| Power Consumption | | Max. 5.6W (Max.4.8W with IR LED Off) |
| Certifications | | FCC, IP66* |
| External Storage**(Optional) | |  (Micro SD (SDHC) Memory Card (>Class 6, up to 32 GB)) |

* Applies to *Vandal dome* models only.

** An SLC (Single Level Cell) or MLC (Multi Level Cell) card by SanDisk or Transcend is recommended to ensure stable recording performance.*

** An SD memory card is a consumable product with a finite service life. Prolonged use will damage the card's memory sectors and result in data loss or memory card failure. Test the SD memory card regularly and replace it whenever necessary.

** microSD Logo is a trademark of SD-3C, LLC.

COSTAR

COSTAR VIDEO SYSTEMS

101 Wrangler, Suite 201 Coppell, Texas 75019

Phone: (469) 635-6800

Fax: (469) 635-6822

Toll-free: (888) 694-7827